## Lamp Post Measurement

# Suyash Agrawal 2015CS10262

July 26, 2017

#### 1 Measuring Height

#### 1.1 Assumptions

- We require the field of view of the camera. Either this can be given in specifications itself or this can be easily calculated by placing an object of known length at a known distance from camera (this gives us the angle subtended ) and dividing the angle with the ratio of the length of object in image by image height. Let us denote the field of view of camera by  $\Omega$ .
- We assume the camera to be kept on the ground and thus field of vision will be reduced by half.
- The object is sufficiently far away that whole of it is visible in the image.

#### 1.2 Basic Equations

$$an \theta = \frac{h}{l} \tag{1}$$

$$\tan \theta' = \frac{h}{l - d} \tag{2}$$

$$\frac{p'}{p} = \frac{\theta'}{\theta} \tag{3}$$




Figure 1: Diagram of situation

$$\frac{p}{W} = \frac{theta}{\Omega/2} \tag{4}$$

From equation 1 and equation 2:

$$h = \frac{d \tan \theta \tan \theta'}{\tan \theta' - \tan \theta} \tag{5}$$

#### 1.3 Procedure

- 1. Take a picture from unknown distance l of the pole. Let the real height of pole be h (vertically from ground). Let picture height be w and height of pole in picture be p.
- 2. Move d distance towards the pole and take a picture. Let the new height of pole in picture be p'.
- 3. Now using equation 4 we can measure angle  $\theta$  and using equation 3 we can measure angle  $\theta'$  .
- 4. Then using equation 5 we measure the vertical height h of pole from ground.

### 2 Measuring Inclination

1. First measure the actual length of pole using:

$$L = (\text{Length of inclined post in pixel}) * \frac{h}{p}.$$
 (6)

2. Then calculate the inclination from vertical using :  $\theta_a = \cos^{-1}(L/h)$